PRO10000 Portable Generator
Illustrated Parts List
Model 030338-0

Briggs & Stratton Power Products GROUP, LLC
Jefferson, Wisconsin, U.S.A.

IPL No. 311887 Rev B (12/04/2009)

Exploded View - Main Unit



Copyright © 2009 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form without the express written permission of Briggs & Stratton Power Products Group, LLC.

Parts List - Main Unit

Item	Part #	Description
1	B204637GS	CRADLE (Includes Items 20 & 31)
2	38353GS	MOUNT-VIBRATION
3	56893GS	CRIMPTITE
4	190220GS	ADAPTER-ENGINE
5	NSP	ALTERNATOR (see page 5)
6	*	NUT-HEX, M8 - 1.25
7	62265GS	GROMMET
8	96796GS	WASHER
9	194208GS	KIT-HARDWARE, HEATSHIELD
10	190274BGS	SCREW
11	187365DGS	SCREW
12	189302SGS	WIRE
13	*	HHCS-M8 - 1.25 x 16
14	*	WASHER-SHAKEPROOF, EXT. 5/16
15	*	WASHER-SHAKEPROOF, EXT. M6
16	B77304GS	SUPPORT-ENGINE
17	75246GS	TAPTITE
18	195404GS	MOTOR-STEPPER
19	J93074GS	SUPPORT-HEATSHIELD
20	B4986GS	DECAL
21	194155GS	MOUNT-VIBRATION
22	87680GS	NUT
23	201348GS	JACK-COAXIAL
24	194951GS	HEATSHIELD
25	191190GS	CAP
26	74908GS	TAPTITE
27	*	HHCS-M8 - 1.25 x 20
28	*	WASHER-5/16 M8 LOCK
29	*	HHCS-M8-1.25 x 25
30	194543GS	KIT-HRDWR, THROTTLE LINKAGE
31	200310GS	DECAL
32	*	NUT-1/4 - 20
33	*	WASHER-1/4 LOCK
34	195422GS	COVER-REAR BEARING
35	791745	KIT-FUEL HOSE (cut to fit)
36	90388GS	SCREW
37	B2153GS	SCREW
38	192376GS	SCREW
39	B4300GS	BOLT
40	198221GS	KIT-HARDWARE FUEL TANK (Includes Qty 4)
41	193272GS	VALVE-FUEL
42	87799GS	SWITCH-ON/OFF
43	691656	CONTACTOR-START
44	196035GS	TANK-FUEL
45	189135GS	CAP-FUEL
46	192351GS	LUG
47	77395GS	NUT
48	195373GS	WIRE
49	95920GS	LINK-STEPPER MOTOR
50	188333GS	DECAL
51	194984GS	DECAL
52	94480GS	DECAL
53	200816GS	BRACKET
54	95349GS	PLATE-ADJUSTMENT
55	197797GS	DECAL
56	202997GS	DECAL
57	189759GS	KIT-FUEL VALVE REPAIR
58	204578GS	PANEL-CONTROL
59	*	WASHER-EXT. #10 SHAKEPROOF
60	193512GS	SUPPORT-BTTRY TRAY
61	95348GS	BRACKET
62	95921GS	LINK-BELL CRANK
63	96717GS	SPRING
65	192724GS	GAUGE
66	*	HHCS-M6-1.0 x 40
68	192985GS	TRAY-BATTERY
69	193043GS	BATTERY
70	*	HHCS-M6 -1.0 x 12
71	*	HHCS-3/8 - 16 x 3/4
72	*	WASHER-3/8, LOCK
73	*	NUT-3/8 - 16
74	193347GS	KIT-HARDWARE BATTERY
75	280623	TUBING-FUEL LINE
76	185939TGS	WIRE
78	189302RGS	WIRE
79	204722GS	DECAL
80	204723GS	DECAL
81	200658GS	DECAL
900	§	ENGINE

Parts Not Illustrated

204730GS	MANUAL-OPERATOR'S
BB3061GS	OIL (Qty 1)
BB3061BGS	OIL (Qty 1)
B4177GS	CHARGER-BATTERY
198800GS	DECAL-Float
197159GS	DECAL-Ignition
43438GS	PLUG-120/240V TL30A
100523GS	PLUG-125V TL30A
65787GS	CABLE-BTTRY CHARGE
690661	SCREW
392390	SPARK-ARRESTER
692099	MUFFLER
691513	BRACKET
692056	SCREW
690898	CLAMP
692539	SCREW

* - Items without part numbers are common fasteners and are available at your local hardware store.

§ - Contact Engine Manufacturer

Exploded View & Parts List - Control Panel



Item	Part #	Description
1	B204581GS	PANEL-CONTROL
2	201864GS	BOX-CONTROL PANEL
3	*	WASHER-FLAT, #10 - M5
4	*	LOCKWASHER-M5
5	*	PPHMS-M5 - 0.8 x 12
6	*	WASHER-M6 - 1/4, INT. SHAKEPROOF
7	78653GS	SWITCH-ON/OFF
8	82538GS	SWITCH-ON/OFF
9	202602GS	METER-HOUR
10	*	LOCKWASHER-M3
11	B4262GS	OUTLET-125/250V 50A
12	*	PHMS-M3 - 0.5 x 10
13	77314GS	RELAY
14	87962GS	BREAKER-CIRCUIT 10A
15	84028GS	TRANSFORMER
16	64525GS	STANDOFF
17	195406GS	BOARD-IDLE CONTROL
18	*	PHTS-6 - 32 x 3/8”
19	92953GS	BLOCK-TERMINAL 50A
20	*	LOCKWASHER-M4
21	*	PPHMS-M4 - 0.7 x 20

Item	Part #	Description
22	*	NUT-M4 - 0.7
23	*	WASHER-FLAT M4
24	192931GS	BRACKET
25	*	WASHER-SHAKEPROOF, INT. #8
26	192828FGS	BREAKER-CIRCUIT 50A
27	68868GS	OUTLET-120V TL30A
28	43437GS	OUTLET-120/240V TL30A
29	68759GS	OUTLET-120V 20A
30	199532GS	STRIP-DUAL ROW
31	193597GS	BLOCK-TERMINAL
32	202394GS	BREAKER-CIRCUIT 20A
33	90418GS	OUTLET-12VDC
34	199528GS	CONNECTOR
35	202033GS	BREAKER-CIRCUIT 30A
36	188632GS	BOOT
37	201171GS	TUBING-FABRIC
38	62265GS	GROMMET

* - Items without part numbers are common fasteners and are available at local hardware stores.

Exploded View & Parts List - Alternator



Item	Part #	Description
1	209599GS	ADAPTER-ALTERNATOR
2	191952GS	ROTOR
3	205062GS	STATOR
4	186060GS	CARRIER-BEARING
5	66449LGS	BOLT
6	66386GS	ASSY-BRUSH
7	66849GS	TAPTITE
8	*	LOCKWASHER-1/4 - M6
9	81917GS	PIN
10	65795GS	RECTIFIER-BATTRY CHRG
11	66849CGS	TAPTITE
12	65791GS	BEARING
13	205858GS	REGULATOR-VOLTAGE

* - Items without part numbers are common fasteners and are available at local hardware stores.

Exploded View & Parts List - Wheel Kit



Item	Part #	Description
1	203273GS	WHEEL
2	*	WASHER-5/8
3	191267TGS	AXLE
4	191265GS	E-RING
5	205135GS	BRAKE
6	*	SCREW-1/4-20 x 3/8
7	B193200GS	HANDLE
	198669GS	GRIP-HANDLE
8	*	WASHER-FLAT, 5/16 - M8
9	*	NUT-M8 - 1.25, NYLOK
10	*	HHCS-M8 - 1.25 x 45
11	*	WASHER-1.2 x 0.346 x 0.03, NYLON
12	B4135GS	PIN

Items Not Illustrated

	205183GS	KIT-HARDWARE, WHEEL

* - Items without part numbers are common fasteners and are available at local hardware stores.